

# **S14I Rugged Laptop Office Docking** User's Manual



PN: 62+030940+03

©2023 Twinhead International Corp and/or its affiliates. All rights reserved.

## **Package Contents**

If any of following items is damaged, please contact your retailer.


Office Docking


Adapter

Power cord









No.	Item
1	Terminal
2	Alignment bracket
3	Lock/Unlock switch
4	Lock latch
5	LAN LED
6	Power button
7	DC-in jack
8	Ethernet port
9	2x USB3.0 ports
10	2x USB2.0 ports
11	DP (DisplayPort) port
12	HDMI port
13	VGA port
14	Serial port
15	Audio out jack
16	Microphone input jack


#### **LED Indicator Behavior**

LAN LED	Indicates the wired network connection status:
	• Green: a link is established.
	<ul> <li>Flashing Green: when there is activity on the port</li> </ul>
Power LED	The LED light stays on when the AC power is plugged in.


#### **Docking the Laptop PC**

1. Align the Laptop PC by the alignment bracket and terminal contact and then place the Laptop PC onto the docking cradle.

Be sure to insert the handle side first as shown the illustration.




2. Slide the Lock/Unlock switch to the lock position to secure the Laptop PC to the docking cradle.




#### **Undocking the Laptop PC**

1. Slide the Lock/Unlock switch to the unlock position to disengage the connection. **Be sure the device is properly turned off.** 






2. Lift to remove the Laptop PC.



- If the Laptop PC is equipped with a second LAN port, its functionality will not be affected while the Laptop PC is locked to the docking cradle.
- If the Laptop PC is equipped with an HDMI port and VGA port, then the VGA port on the Laptop PC is disabled while the Laptop PC is locked to the docking cradle.
- If the Laptop PC is equipped with dual mini DP ports and VGA port (or dual LAN ports), then the mini DP port on the right side is disabled while the Laptop PC is locked to the docking cradle.

000000



### Federal Communications Commission Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Warning: Operation of this equipment in a residential environment could cause radio interference.

#### **IC Regulations**

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conform à la norme NMB-003 du Canada.

#### **Twinhead International Corp.**

11F, No.550, Ruiguang Rd., Neihu, Taipei 11492, Taiwan, R.O.C.