

Rugged Notebook PC

S14I User's Manual



Table of Contents

BEFORE YOU START	5
PACKAGE CONTENTS	5
PRODUCT OVERVIEW	6
<i>Front View</i>	6
<i>Back View</i>	7
<i>Right View</i>	8
<i>Left View</i>	9
<i>Rear View</i>	10
STATUS INDICATORS	11
GETTING STARTED	12
INSTALLING THE BATTERY.....	12
<i>Charging the Battery</i>	12
<i>Charging Time</i>	13
<i>Checking the Battery Level</i>	13
<i>When to replace the Battery Pack</i>	13
<i>Removing the Battery</i>	14
USING THE SECONDARY BATTERY	14
<i>Installing the Secondary Battery</i>	14
<i>Removing the Secondary Battery</i>	15
USING THE MAIN STORAGE	16
<i>Installing the Main Storage</i>	16
<i>Removing the Main Storage</i>	18
CONNECTING TO POWER.....	20
<i>Connecting the AC Adapter</i>	20
<i>Using Battery Power</i>	20
<i>Configuring the Power Settings</i>	21
STARTING YOUR NOTEBOOK	22
<i>Turning On Your Device</i>	22
<i>Turning Off Your Device</i>	23
USING THE KEYBOARD	24
USING THE TOUCH PAD.....	26
OPERATING YOUR NOTEBOOK.....	27
USING THE QUICKMENU	27
<i>QuickMenu Overview</i>	27
<i>Viewing the Version Information</i>	28
<i>Viewing the Battery Charge Cycles</i>	28
<i>Battery Charging Protection Setting</i>	29
<i>Configuring the Programmable Button (P1)</i>	30
<i>Configuring the Programmable Button (P2)</i>	30
<i>Assigning an Application to the P1/P2 Button</i>	31

<i>Accessing the Mobility Center</i>	31
<i>Configuring the Touchscreen Settings</i>	32
<i>Configuring External Antenna Switching Mode</i>	33
USING THE CAMERA	34
<i>Opening Camera App</i>	34
<i>Taking Photos</i>	35
<i>Recording Videos</i>	36
<i>Switching Between Modes</i>	37
<i>Enable HDR Function</i>	37
<i>Windows Studio Effects</i>	38
<i>Setting Photo Timer</i>	38
<i>Configuring Camera Settings</i>	38
<i>Viewing Photos/Videos</i>	40

MAKING CONNECTIONS..... 41

INSTALLING THE MEMORY CARD	41
INSTALLING THE SIM CARD	42
INSTALLING A SMART CARD	43
CONNECTING THE MICROPHONE/HEADSET.....	44
CONNECTING USB DEVICES	45
CONNECTING TO EXTERNAL DISPLAYS	46
CONNECTING TO A LOCAL AREA NETWORK (LAN)	47
CONNECTING TO WIRELESS CONNECTIONS.....	48

USING THE BIOS SETUP UTILITY..... 59

BIOS SETUP MENU	59
MAIN MENU	61
ADVANCED MENU	62
BOOT MENU	68
SECURITY MENU	70
SAVE & EXIT MENU	71

MAINTAINING AND CARING FOR YOUR NOTEBOOK..... 72

PROTECTING YOUR NOTEBOOK	72
STORING AND HANDLING YOUR NOTEBOOK	72
CLEANING YOUR NOTEBOOK	75
TRAVELING WITH YOUR NOTEBOOK	76

TROUBLESHOOTING..... 77

PRELIMINARY CHECKLIST	77
SOLVING COMMON PROBLEMS	77
DISPLAY PROBLEMS	79
HARD DISK PROBLEMS	80

OTHER PROBLEMS	83
----------------------	----

APPENDIX 84

COPYRIGHT	84
SPECIFICATIONS	84
REGULATORY STATEMENT	88
<i>Federal Communications Commission Statement</i>	88
<i>IC Regulations</i>	88
<i>Declaration of Conformity</i>	89
<i>FCC RF Radiation Exposure Statement</i>	89
<i>EU RoHS</i>	89
<i>REACH - Substances of Very High Concern (SVHC)</i>	89
<i>Cybersecurity Information</i>	90
<i>Battery Statement</i>	90
<i>Battery Disposal</i>	91
<i>CLASS 2 LASER PRODUCT</i>	91
SAFETY INSTRUCTIONS	93
SHOPFLOOR DATE CODE FORMAT DESCRIPTION	95

Before You Start

Congratulations on your purchase of this notebook.

This semi-rugged notebook is portable and provides users with maximum mobile computing experience in a wide range of working environments. Before you begin using your notebook, read this chapter to familiarize yourself with the main components installed in the system.

Package Contents

If any of the following items is damaged, please contact your retailer.



Notebook



Power cord



DC 19V 90W power adapter
(Optional DC 19V 120W with
NVIDIA® VGA)



Standard 9-cell Li-ion
Battery



Stylus and tether
(Touch-panel model only)



NOTE

- These pictures are for reference only. Actual items may slightly differ.
- Declaration of product weight: 2.37kg. The actual weight may vary by configuration.

Product Overview

Front View



No.	Item	Description
1	Front camera	Use to take pictures, record videos, or video conference.
2	Camera cover	Protects the camera.
3	Microphones	Records the surrounding sound.
4	Display screen	Optional capacitive touch panel.
5	Programmable buttons (P1/P2)	Press to enter the chosen program (user definition).
6		
7	Status indicators	Indicates the corresponding function status.
8	Power button	Press to turn your notebook on or off.
9	Waterproof keyboard	Press the keys to input information.
10	HF/LF RFID reader (optional)	Read tags for data collections from other devices.
11	Fingerprint scanner (optional)	Scans fingerprints for biometric identification.

No.	Item	Description
12	Touch pad	Use to point, select, drag, or scroll objects on the screen.
13	Touch pad button	Press to select objects or display a shortcut menu.

Back View



No.	Item	Description
1	Docking connector	Connects the notebook to a docking station.
2	RF Pass-thru connectors (x3) (optional)	Use for the external antenna of WWAN, GPS, and WLAN.
3	Battery latch	Slide to the unlock position to release the battery.
4	Speakers	Emits sound.

Right View



No.	Item	Description
1	Battery pack (optional)	2 nd removable quick-release battery (optional) with physical power indicator.
2	Audio Combo jack	Connects to headphones, external speakers, or microphone.
3	USB 3.2 (Gen 1) port	Connects to USB 3.2 peripheral devices.
4	USB 3.2 (Gen 2) port	Connects to USB 3.2 peripheral devices.
5	Serial port	Connects to serial (RS232/422/485) peripheral devices.
6	RJ-45 port	Connects to a local area network (LAN) using an Ethernet cable.
7	DC-in jack	Connects to the power adapter.

Left View



No.	Item	Description
1	Kensington lock slot	Connects to a Kensington-compatible notebook security lock.
2	Optional Serial port + USB 3.2 (Gen 1) port	Optional for Express Card 54 or Smart Card Reader or 2 nd Serial Comport + USB 3.2 Gen 1 (type-A) x1 or Barcode Scanner.
3		
4	Storage drive latch	Slide to lock/unlock the storage drive.
5	Storage drive (main)	Removable quick-release storage.
6	Stylus compartment	Contains the stylus.
7	Battery pack	Main removable quick-release battery with physical power indicator.

Rear View



No.	Item	Description
1	Thunderbolt 4 (Type-C) port	Connects to USB Type-C peripheral devices.
2	HDMI port	HDMI port: Connects to an HDMI device such as an external HDMI LCD TV.
3	RJ-45 port	Connects to a local area network (LAN) using an Ethernet cable.
4	Nano SIM card slot	Use to insert a SIM card.
5	Smart card reader (optional)	Use to insert smart card.
6	Card reader	Use to insert memory cards to transfer pictures, music, and data between your notebook and flash compatible devices. The card reader supports SD (Secure Digital) and microSDXC.



NOTE

- Smart card reader and RFID reader are mutually exclusive.

Status Indicators

The status indicators light up when a particular function of the notebook is active. Each indicator is marked with a symbol.



Icon	Item	Description
	Power	The LED light stays on (blue) when the system is running.
 	Battery	Indicates the battery status: - Green: when the battery is fully charged (95% or above) - Orange: when the battery is charging - Flashing orange: charging error - Red: when the battery capacity is lower than 7% - Off: when discharged
	RF LED	Indicates the wireless connection status: - Blue: Any of the RF features (WLAN/Bluetooth/WWAN) are activated. - Off: None of the RF features (WLAN/Bluetooth/WWAN) are activated.
	Wired LAN	Indicates the wired network connection status: - Green: a link is established - Flashing Green: when there is activity on the port
	Storage	Lights up (green) when the SSD is accessing data.
	Num Lock	Lights up (green) when Num Lock is activated.
	Caps Lock	Lights up (green) when Caps Lock is activated.

Getting Started

This chapter will help you get started using the device.

CAUTION!

Before any internal installation procedures are carried out on the system, make sure the system is turned off and cooled down for 5 minutes. Failing to turn off the system before opening it can cause permanent damage to the system and serious or fatal injury to the user.

Installing the Battery

To install the battery, follow the steps below:

1. Insert the battery into the battery compartment, as shown in the image below.



2. Push completely until the battery locks into place.



NOTE

- The system will stay operating within 300 seconds when user swaps the battery.

Charging the Battery

The Li-Ion battery is not fully-charged upon purchase.

To charge the battery, follow the steps below:

1. Install the battery into your notebook. See procedures above.
2. Connect the AC adapter to the DC-in jack on your notebook.
3. Connect the AC adapter to the power cord.
4. Plug the power cord into an electrical outlet.

Charging Time

It takes approximately 3.5 hours (at 25°C) to fully charge the battery.



NOTE

- The charging time may be longer if you are using your notebook while charging the battery.


CAUTION!

- **DO NOT charge the battery if the temperature is below 0°C or higher than 45°C.**
- **Use only the supplied AC adapter. Using other AC adapters may damage the battery or your notebook.**

Checking the Battery Level

It is important that you monitor the battery status regularly to ensure you do not run out of power at a critical moment.

To check the remaining battery power, hover the cursor over the battery icon (🔋) in the system tray.



When to replace the Battery Pack

The battery performance gradually decreases over time and usage. We recommend you replace your battery pack after 18 to 24 months of usage.

Removing the Battery

To remove the battery, follow the steps below:

1. Press and hold the battery latch release button. Then pull the battery out to disengage it from its compartment.
2. Pull the battery out of the battery compartment.



Using the Secondary Battery

Installing the Secondary Battery

To install the secondary battery, follow the steps below:

1. Insert the secondary battery into the battery compartment, as shown in the image below.



2. Push completely until the secondary battery locks into place.

Removing the Secondary Battery

To remove the secondary battery, follow the steps below:

1. Press and hold the battery latch release button. Then pull the optional battery out to disengage it from its compartment.
2. Pull the secondary battery out of the battery compartment.



Using the Main Storage

Installing the Main Storage

To install the main storage, follow the steps below:

1. Open the I/O device cover.



2. Insert the main storage into the media bay compartment. Then push completely until the main storage locks into place.



3. Slide the main storage latch to the lock position to secure the main storage in place.



4. Close the I/O device cover.



Removing the Main Storage

To remove the main storage, follow the steps below:

1. Open the I/O device cover.



2. Slide the main storage latch to the unlock position to release the main storage.



3. Pull the main storage out of the media bay compartment.



4. Close the I/O device cover.



Connecting to Power

Your notebook can be powered up using the AC adapter or the Lithium-ion battery.

Connecting the AC Adapter

The AC adapter powers up your notebook and charges the battery.



1. Connect the AC adapter to the DC-in jack on your notebook.
2. Connect the AC adapter to the power cord.
3. Plug the power cord to an electrical outlet.

Using Battery Power

1. Install the charged battery in the battery compartment.
2. Remove the AC adapter (if plugged in). Your notebook will automatically use the battery power.




NOTE


- If your notebook is connected to an electrical outlet and the battery is installed, your notebook uses power from the electrical outlet.

Configuring the Power Settings

1. Search for "Edit power plan". Then tap **Open**.



2. Change the desired sleep and display settings. Then tap **Save changes**.



Starting Your Notebook

Turning On Your Device

1. To open the display panel, unlock the chassis latch to open the notebook chassis.



2. Lift the cover lid to upright position.
3. Press the  button until the Power LED lights up.



TIP


Besides using the keyboard or touch pad for operations on your notebook, you can also use a mouse. To use a wired mouse, simply plug it into an available USB port.

Turning Off Your Device

It is important to properly shut down your notebook to avoid the loss of unsaved data. To shut down your notebook, do the following:

Tap  >  > **Shut down**.

Wait for your notebook to turn off power completely before removing the power source (if necessary).



NOTE

- When closing the cover lid, make sure to press the chassis latch firmly until it locks into place.



Using the Keyboard



No.	Keys	Description
1	Function keys	These function keys are used to perform designated tasks. The tasks for each key may vary from one application to another.
2	[Fn]	Press the [Fn] key in combination with other keys to execute a command.
	[Fn] + F1	Toggles the display on/off.
	[Fn] + F2	Toggles between LCD, external display, or both.
	[Fn] + F3	Switches to suspend mode.
	[Fn] + F4	Decreases the keyboard illumination.
	[Fn] + F5	Increases the keyboard illumination.
	[Fn] + F6	Decreases the display brightness.
	[Fn] + F7	Increases the display brightness.
	[Fn] + F8	Decreases the audio volume.
	[Fn] + F9	Increases the audio volume.
	[Fn] + F10	Toggles the audio mute on/off.
	[Fn] + Left Shift	Toggles the keyboard backlight on/off.

No.	Keys	Description
		 NOTE This option is not available if the BIOS keyboard backlit timer setting is set to Off.
	[Fn] + Right Alt	Toggles the touchpad on/off.
3	Windows key	Press to display the Start menu. This action is the same as tapping the Start icon.
4	Copilot key	Press to launch the Copilot.
	Application key	Press the [Fn] and [] keys to display an application shortcut menu. This action is the same as right-clicking a mouse button.
5	Numeric keypad	Press the NumLock key to activate the numeric keypad. Press the keys on the numeric keypad to enter numbers or operands as you would on a calculator.

Using the Touch Pad

The touch pad is a cursor-pointing device that provides all the features of a two-button mouse. Its primary function is to move the cursor around the screen. You can also point, select, or drag items or objects on the screen.



Point

Slide your finger on the touch pad to point the cursor to an item or object on the screen.

Click

To left-click, move the cursor to the item or object on the screen, then lightly tap the touch pad or press the left button.

To right-click, move the cursor to the item or object on the screen, then press the right button.

Double-click

To double-click, move the cursor to the item or object on the screen, then tap the touch pad twice or press the left button twice.

Drag

To drag an item or object, press and hold the left button then slide your finger on the touch pad to move the item or object.

Scroll

To scroll through a page, place two fingers on the touch pad and slide horizontally or vertically to scroll.


Operating Your Notebook

This chapter will guide you through how to use your notebook.


Using the QuickMenu

To enter the Quick menu, tap the arrow in the system tray to display hidden icons.

Then tap the Quick Menu icon (⚙️).



QuickMenu Overview



NOTE

- If the tab is green (i.e. , the current function is activated.


Viewing the Version Information

In the **Version** section, you can view the Bios version, EC version, and Quick Menu version.




Viewing the Battery Charge Cycles

In the **Battery Charge Cycles** section, you can view the battery charge cycle and battery status.



Battery Charging Protection Setting

On the **Battery Charging Protection Setting** section, select the protection setting.



NOTE


- Tap  to view a detailed description of each battery charging protection mode.

There are four available options:

- **Regular Mode:** In this mode the battery will be fully charged.
- **Optimized Battery Charging (OBC):** Battery charging will stop at 80% to reduce battery aging.
- **Temperature Control Mode (TCM):** To extend the lifetime of the battery, charging is enhanced based on DURABOOK intelligent algorithm and battery temperature.
- **DURA² Charging (D2C):** To maximize battery performance and lifespan, charging is enhanced based on DURABOOK intelligent algorithm and battery temperature. Battery charging will stop at 80%.

Configuring the Programmable Button (P1)

In the **P1 Button Setting** section, you can assign the function for the **P1** button.




There are three available options:

- **Stealth Mode:** Turns off the LCD backlight, LEDs, speakers, and camera flash.
- **Night Vision Mode:** Adjusts the brightness of the LCD under 1.7 nits and turns off the LEDs and camera flash.
- **Launch Application:** Shortcut key for launching specific applications. To assign the application, refer to the "Assigning an Application to the P1/P2 Button" section.
- **Disable:** No function.

Configuring the Programmable Button (P2)

On the **P2 Button Setting** section, you can assign the function for the **P2** button.




There are four available options:

- **Touch Screen Mode:** Toggles the touch screen mode.
- **Launch Application:** Shortcut key for launching the specific application. To assign the application, refer to the "Assigning an Application to the P1/P2 Button" section.
- **Disable:** No function.


Assigning an Application to the P1/P2 Button

Tap the **P1-Key** or **P2-Key** tab to assign an application to the **P1** or **P2** button, respectively. Select the desired application and tap **Open**.



Accessing the Mobility Center

Tap the **Mobility Center** tab to adjust or configure the brightness, volume level, mute function, battery status, screen orientation, external display, sync, and presentation settings.



Configuring the Touchscreen Settings

The touchscreen is an optional feature for this notebook. When installed, it supports navigation using touch gestures from your finger, a stylus, or with a glove.

CAUTION!


Do not use any sharp objects, such as a pen or pencil, on the touchscreen to prevent scratches.



NOTE

- An optional protective film has been attached to the screen before shipment. You should change the film when it gets worn out.

You can select the desired touch screen mode in the QuickMenu.



Select one of the available options:

- : Select **Finger/Water** if you are using your fingertips.
- : Select **Glove** if you are wearing gloves.
- : Select **Stylus** if you are using a stylus.
- : Select **Disable** to disable the touch function.




NOTE

- If the touchscreen mode is set to **Glove** or **Stylus** and the touchscreen is wet (i.e. from a spilled liquid), the touch function will not respond to any input. Make sure to keep the screen dry to ensure proper operation.
- If you assign the **P2** button as **Touch Screen Mode** (refer to page 30), you can easily switch the touchscreen mode by simply pressing the **P2** button.

Configuring External Antenna Switching Mode

Select the respective external antenna tab to configure the setting.



- Tap the **WIFI Antenna** tab to enable/disable the device to automatically switch to the external WLAN antenna when it is affixed on a docking station.
- Tap the **LTE Antenna** tab to enable/disable the device to automatically switch to the external WWAN antenna when it is affixed on a docking station.
- Tap the **GPS Antenna** tab to enable/disable the device to automatically switch to the external GPS antenna when it is affixed on a docking station.



NOTE


- If the tab is green, this indicates the current function is activated.

Using the Camera

Using the Camera application, you can use this notebook to take photos or videos.


Opening Camera App

To access the Camera application, search for “camera” and then tap **Open**.




Taking Photos

Tap  to capture a photo.



Recording Videos

1. Tap  to switch to Video mode.




NOTE

- You can also toggle / to switch to Video mode.

2. Tap  to start recording a video.

The recording time appears on the bottom of the screen.

3. During the video recording, you can do the following:



- Tap  to pause the recording. To resume, tap .
- Tap  to stop recording the video.

Switching Between Modes

Tap on your preferred shooting mode. If the mode is not visible, tap / to see more shooting modes:

- : Record a video.
- : Take a photo.
- : Scan a barcode.

Enable HDR Function

Tap  to enable HDR function.

- To disable this function, simply tap .

Windows Studio Effects

Tap  to enable automatic framing, portrait light, eye contact, background effects, and creative filters.


Setting Photo Timer

Tap  to toggle the desired time delay.

-  : Self-timer is off
-  : 2-second self-timer
-  : 5-second self-timer
-  : 10-second self-timer

Configuring Camera Settings

1. Tap  to enter the Settings menu.




2. Select the desired menu option and setting.

Menu Option	Description
Camera settings	
Show advanced controls for photos and videos	Enable or disable to show advanced controls for photos and videos.
Framing grid	Hide the framing grid lines or select the framing grid type.
Default settings	Select between custom in-app settings and system settings. These settings apply to the Camera app at the start of each session.
Open camera system settings/Open audio system settings	Open Windows Settings for configuring camera or adjusting audio respectively.
Photo settings	
Photo quality	Select the photo resolution and aspect ratio.
Time lapse	Enable or disable taking photos continuously until the camera button is pressed again.
Videos settings	
Video quality	Set the video resolution, aspect ratio, and frame rate.
Flicker reduction	Select the suitable frequency rate (50Hz or 60Hz) to reduce the flicker effect when recording video under fluorescent light.
Related settings	
Choose whether camera can use location info, change privacy settings, or try out experimental features.	
About	
Camera	Check the camera version and read the related regulatory information.
Send feedback	Send feedback about the Camera app.
Help	Read help topics online.

Viewing Photos/Videos

After taking a photo or recording a video, tap the thumbnail (on the bottom-right corner) to view the most recent photo or video taken.



Swipe right to see other photos or videos in your collection.

Making Connections

This chapter will guide you through installing peripheral devices to maximize the use of your notebook.

Installing the Memory Card

Your notebook supports different types of memory cards to provide faster data transfer.

Supported types: microSDXC

1. Pull to open the I/O port cover.



2. Push the memory card into the memory card slot until it clicks into place.



3. Close the I/O port cover.

Installing the SIM Card

You can use a SIM card for wireless internet access.



NOTE

- Check the availability of service and data plan rates with your network service provider.

1. Open the I/O port cover.



2. Remove the two (2) screws securing the SIM card slot cover to the device.
3. Remove the nano SIM card slot cover.



4. Push a valid SIM card into the slot until it clicks into place.



5. Close the I/O port cover.

Installing a Smart Card

Your notebook is equipped with a built-in smart card reader that allows you to make secure purchases, store security information, and provide identification and information using a smart card.

1. Open the I/O port cover.



2. Insert a smart card into the smart card slot.



3. Close the I/O port cover.


Connecting the Microphone/Headset

Your notebook is equipped with an audio combo jack that enables you to use the headset or microphone.

1. Open the I/O port cover.



2. Plug the stereo headphones cable into the audio combo jack of your device.



NOTE

- The headset and microphone are not included in the package. They are sold separately.

Connecting USB Devices

You can connect your notebook to other USB devices, such as a mouse, keyboard, digital camera, printer, or an external hard disk drive.

1. Open the I/O port cover on the left or right side of the notebook.



2. Connect one end of the USB cable to the USB port of your device.



3. Connect the other end of the cable to the USB device (if necessary).



NOTE


- A USB cable is not included in the package. It is sold separately, or it may come with your USB device.

You can connect an additional display to your notebook by using the DisplayPort or HDMI via USB type-C or HDMI cable.

1. Open the I/O port cover.



2. Connect one end of the DisplayPort or HDMI cable to the USB type-C or HDMI port of your device.



3. Connect the other end of the cable to the external display.



NOTE

- The DisplayPort or HDMI cable is not included in the package. It is sold separately.

Connecting to a Local Area Network (LAN)

Making Connections

You can connect your notebook to a local area network (LAN) using the Ethernet cable.

1. Open the I/O port cover right or rear side of the notebook.



2. Connect one end of the Ethernet cable to the RJ-45 port of your notebook.



3. Connect the other end of the Ethernet cable to the router.



NOTE

- The Ethernet cable is not included in the package. It is sold separately.

Connecting to Wireless Connections


You can connect your notebook to a Bluetooth device, wireless local area network (WLAN), or WWAN.

**NOTE**

- Do not disassemble the bumper. Otherwise, the antenna may be damaged, resulting in poor reception.

Opening the Quick Settings menu

To open the Quick Settings menu, tap a set of status icons (wireless/cellular connection, volume level/mute, and battery) in the lower-right corner of the screen.




Connecting to a Bluetooth Device

Your notebook can connect and communicate with other Bluetooth-enabled devices.

Making Connections

To add a device, follow the steps below:

1. Open the Quick Settings menu (refer to page 49).
Then tap **Bluetooth** icon to enable the function.




2. Tap the arrow icon (>) next to the Bluetooth icon.
3. Select the device you want to connect. Then follow the on-screen instructions to pair the devices.




NOTE

- The pairing method varies depending the type of device you are pairing with. You may be prompted to enter the pairing code, confirm the pairing code, or the device will pair automatically.
For example,



When the pairing process is complete, the connection status will show "Connected".

**NOTE**


- If the device that you want to add does not appear on the screen, please check if the device is turned on and discoverable.
- Most Bluetooth-enabled devices need to be paired with your notebook. The PIN you enter on the notebook must be the same PIN to be entered on the other Bluetooth device.
- Once a partnership has been created, connecting to that device again will no longer require entering the PIN.
- To disconnect from the Bluetooth-enabled device, select the device in the Bluetooth menu (**Settings > Bluetooth & devices**) and tap **⋮ > Remove device**.

Connecting to a Wireless Local Area Network


Your notebook comes with a WLAN module. A wireless network can be added either when the network is detected or by manually entering the settings information.

To connect, follow the steps below:

1. Open the Quick Settings menu (refer to page 49). Then tap **Wi-Fi** icon to enable the function.



2. Tap the arrow icon (>) next to the Wi-Fi icon.
3. Tap the desired wireless network.




4. Tap **Connect**.
Some networks require a network security key or a password.



TIP

Check the **Connect automatically** box to automatically connect to this network when it is available.

5. Enter the network security key.



6. Tap **Next**. After the connection is established, you can see the wireless icon () on the taskbar.



NOTE

- Wi-Fi access requires service from a wireless service provider. Contact your service provider for more information.
- Actual wireless connectivity will depend on the system configuration. Please contact your dealer for more information.
- To disconnect from the wireless network, select the network in the wireless network list and tap **Disconnect**.


Connecting to a Wireless Wide Area Network (WWAN)

The **WWAN** function allows your notebook to connect to the Internet using mobile or cellular data networks.

To connect, follow the steps below:


1. Insert a valid SIM card into the SIM card slot.

2. Open the Quick Settings menu (refer to page 49).
Then tap **Cellular** icon to enable the function.



3. Tap the arrow icon (>) next to the Cellular icon.

4. Select the mobile network carrier to establish the connection.




TIP

Check the **Let Windows keep me connected** box to allow the system to automatically connect to this mobile data network.


Connecting to a Wireless Wide Area Network (WWAN) by eSIM

To connect, follow the steps below:

1. Contact your mobile carrier to get an eSIM plan. They will either provide you with a QR code, a downloadable profile, or an activation code.
2. Open the Quick Settings menu (refer to page 49). Then tap **Cellular** icon to enable the function.




3. Tap the arrow icon (>) next to the Cellular icon.
4. Tap **More cellular settings**.




Making Connections


5. In the ***Use this SIM for cellular data*** option, select **SIM 2**.




6. Scroll down and select **eSIM profiles**.



7. In the **Add an eSIM profile from your mobile operator** option, select **Add profile**.




8. Select **Let me enter an Activation code I have from my mobile operator**. Then tap **Next**.



Making Connections

9. Scan the QR code provided by your carrier or enter the details manually if required. Then follow the on-screen instructions to complete the setup.



Using the BIOS Setup Utility

Your notebook has a BIOS setup utility which allows you to configure important system settings, including settings for various optional functions on the notebook. This chapter explains how to use the BIOS setup utility.

BIOS Setup Menu

The BIOS Setup Utility allows you to configure your notebook's basic settings. When you turn on your notebook, the system reads this information to initialize the hardware so that it can operate correctly. Use the BIOS setup utility to change your notebook start-up configuration. For example, you can change the system's security and power management routines.


Starting the BIOS Setup Utility

You can only enter the BIOS setup utility as the notebook is booting, i.e., between the time you turn on the notebook and before the Windows interface appears.

If your notebook is already on, shut down your notebook completely (power off), restart it, and then press the **Del** button on the keyboard to enter the setup utility.

Selecting the Boot Device

Restart your notebook and press the **F12** button on the keyboard when the DURABOOK logo appears. Then select the boot device.



Navigating and Entering Information in BIOS


Use the following keys to move between fields and to enter information:

Keyboard	Description
→ ←	Select screen
↑ ↓	Select item
Enter	Select
+ / -	Change Opt.
F1	General Help
F2	Previous Values
F3	Optimized Defaults
F4	Save & Exit
Esc	Exit

Users are allowed to enter new values to replace the default settings in certain fields, and the rest of the fields are specified by system default parameters and cannot be modified by users. Reverse the attribute of the main options and press the **Enter** button to enter into the submenu. Press the **Esc** button to return to the previous configuration page. To display the Help, screen at any time, simply press the **F1** button.

Main Menu


The Main menu displays the device’s system overview information, including the system date and time.



Item	Description
BIOS Information	Displays the BIOS version detected during boot up.
System Information	Displays the CPU type and speed, total memory, mainboard version, UEFI firmware version, processor type, ME FW version, ME Firmware SKU, serial number, and UUID.
System Date	Sets the system date.
System Time	Sets the system time.

Advanced Menu

The Advanced menu allows you to configure specific system settings.



Item	Description
CPU Configurations	Configure the CPU parameters. For details, refer to CPU Configurations on page 63.
Programmable Buttons	Assign the function for the P1 button. For P1 button, the available options: Stealth Mode (by default), Night Vision Mode, Programmable Function, or Disabled (no function).
Device Configurations	Configure the device settings. For details, refer to Device Configurations on page 64.
Antenna Switching Configurations	Configure the external antenna settings. For details, refer to Antenna Switching Configurations on page 66.
Power Configurations	Configure the power management settings. For details, refer to Power Configurations on page 67.
TPM Configurations	Configure Trusted Computing settings.
Battery Calibrations	Perform the battery calibration.
Touch Screen Mode selection	Select the touchscreen mode. For details, refer to Touch Screen Mode SelectionTouch Screen Mode Selection

Item	Description
	on page 67.
UART port1 Mode selection	Set the UART port1 mode. This function is supported only in some specific models or SKUs.
UART port2 Mode selection	Set the UART port1 mode. This function is supported only in some specific models or SKUs.

CPU Configurations

Select this option to configure the CPU parameters.

Item	State	Description
Intel (VMX)/ (SMX/TXT) Virtualization Technology	Enabled	Turn on the function. The default value is [Enabled].
	Disabled	Turn off the function.
VT-d	Enabled	Turn on the function. The default value is [Enabled].
	Disabled	Turn off the function.
Intel Trusted Execution Technology	Enabled	Turn on the function.
	Disabled	Turn off the function. The default value is [Disabled].

Device Configurations

Select this option to configure the device settings.

Item	State	Description
USB Type A Port 1 with USB Charge	Enabled	Turn on the function.
	Disabled	Turn off the function.
USB Type A Port 2	Enabled	Turn on the function.
	Disabled	Turn off the function.
Type C	Enabled	Turn on the function.
	Disabled	Turn off the function.
LAN 1	Enabled	Turn on the function.
	Disabled	Turn off the function.
LAN 2	Enabled	Turn on the function.
	Disabled	Turn off the function.
SD Card Reader	Enabled	Turn on the function.
	Disabled	Turn off the function.
TPM Device	Enabled	Turn on the function.
	Disabled	Turn off the function.
HD Audio	Enabled	Turn on the function.
	Disabled	Turn off the function.
Fingerprint Scanner (Optional)	Enabled	Turn on the function.
	Disabled	Turn off the function.
Touch Screen (Optional)	Enabled	Turn on the function.
	Disabled	Turn off the function.
Smart Card reader (Optional)	Enabled	Turn on the function.
	Disabled	Turn off the function.
RFID (Optional)	Enabled	Turn on the function.
	Disabled	Turn off the function.
Front Camera	Enabled	Turn on the function.

Item	State	Description
	Disabled	Turn off the function.
Barcode Scanner (Optional)	Enabled	Turn on the function.
	Disabled	Turn off the function.
Expansion Bay (Optional)	Enabled	Select the item to turn on Express Card 54 or additional Type-A x2 or 2 nd COM + Type-A x1.
	Disabled	Select the item to turn off Express Card 54 or additional Type-A x2 or 2 nd COM + Type-A x1.
Intel AMT	Enabled	Turn on the function.
	Disabled	Turn off the function.
WLAN	Enabled	Turn on the function.
	Disabled	Turn off the function.
Bluetooth	Enabled	Turn on the function.
	Disabled	Turn off the function.
WWAN (Optional)	Enabled	Turn on the function.
	Disabled	Turn off the function.
GPS (Optional)	Enabled	Turn on the function.
	Disabled	Turn off the function.

**NOTE**

- By default, all settings are set to [Enabled], except for Expansion-Slot Hot-Plug.
- If the configuration without the optional items, the functions will be disabled in BIOS.

Antenna Switching Configurations

Select this option to configure the external WWAN, WLAN, or GPS antenna settings.

Item	State	Description
Switch to External WWAN Antenna	Enabled	Switch to the external WWAN antenna when it is affixed on a docking station.
	Disabled	Turn off the function.
Switch to External WLAN Antenna	Enabled	Switch to the external WLAN antenna when it is affixed on a docking station.
	Disabled	Turn off the function.
Switch to External GPS Antenna	Enabled	Switch to the external GPS antenna when it is affixed on a docking station.
	Disabled	Turn off the function.



NOTE

- By default, all settings are set to [Disabled].

Power Configurations

Select this option to configure the power management settings.

Item	State	Description
Keyboard Backlight Timer Settings	Off / 5/10/15/20/30/40/50/60/80/100/120/240 Minutes	Configure the length of time the keyboard backlight will remain on.
Resume on AC Power	Enabled	Turn on the function.
	Disabled	Turnoff the function.
RTC Wakeup Support	Enabled	Turn on the function.
	Disabled	Turn off the function.
USB always on charging	Enabled	Turns on the function.
	Disabled	Turn off the function.
Battery Charging Protection	Regular Mode	The battery will be fully charged.
	Optimized Battery Charging (OBC)	Battery charging will stop at 80% to reduce battery aging.
	Temperature Control Mode (TCM)	To extend the lifetime of the battery, charging is enhanced based on DURABOOK intelligent algorithm and battery temperature.
	DURA ² Charging (D2C)	To maximize battery performance and lifespan, charging is enhanced based on DURABOOK intelligent algorithm and battery temperature. Battery charging will stop at 80%.


Touch Screen Mode Selection

Select this option to configure the touchscreen mode.

Item	Description
Finger/Water mode	Select this mode for fingertip operation. When the screen gets wet, your finger will be rejected as an input. This mode is set as the default operation mode.
Glove mode	Select this mode if you are wearing gloves.
Stylus mode	Select this mode if you are using the stylus.

Boot Menu

The Boot menu allows you to configure the boot settings and boot sequence.



Item	Description
Bootup NumLock State	Select the keyboard NumLock state.
Launch Network PXE OpRom	Select the LAN PXE boot mode.
VMD setup menu	Configure VDM settings. For details, refer to VMD Setup Menu on page 69.
Intel(R) Rapid Storage Technology	Manage RAID volumes on the Intel® RAID Controller.
Boot Option Priorities	Set the system boot order.


VMD Setup Menu

Select this option to configure VDM settings.

Item	State	Description
Enable VMD Controller	Enabled	Turn on the function. The default value is [Enabled].
	Disabled	Turn off the function.
Enable VMD Global Mapping	Enabled	Turn on the function. The default value is [Enabled].
	Disabled	Turn off the function.
Map this RP B0D6F1 Under VMD	Enabled	Turn on the function. The default value is [Enabled].
	Disabled	Turn off the function.
Map this RP B0D28F0 Under VMD	Enabled	Turn on the function. The default value is [Enabled].
	Disabled	Turn off the function.

Security Menu


The Security menu allows you to set or change the Administrator and User passwords.



Item	Description
Administrator Password	Sets the administrator password.
Secure Boot	Customizes the Secure Boot settings.

Save & Exit Menu

The Save & Exit menu allows you to save/discard the changes and restore the default values for all setup options before leaving the BIOS Setup Menu.



Item	Description
Save Changes and Reset	Resets the system after saving any changes.
Discard Changes and Reset	Resets the system setup without saving any changes.
Restore Defaults	Restores the default values for all the Setup options.
Boot Override	Displays all available boot options from the Boot Option List.

Maintaining and Caring for Your Notebook

Taking care of your notebook will reduce the risk of damage to your device and ensure that it operates properly.

To help you maintain the quality and function of your notebook, this chapter provides guidelines on how to protect, store, clean, and travel with your device.

Protecting Your Notebook

To safeguard the integrity of the data stored on your notebook as well as the device, please follow the precautions described below:

- Install an anti-virus program to monitor potential viruses that could damage your files.
- Use a Kensington cable lock to protect your notebook against theft. Cable locks are available for purchase from online retailers and in most stores that sell computers.
- To use the lock, loop the lock cable around a stationary object such as a table. Then, insert the lock into the Kensington lock hole and turn the key to secure the lock. Store the key in a safe place.

Storing and Handling Your Notebook

General Storage and Handling Guidelines

- Use your notebook at the recommended temperature—between 0°C (32°F) and 55°C (131°F)—to ensure optimal performance (Actual operating temperature depends on product specifications.)
- Avoid placing your notebook in a location subject to high humidity, extreme temperatures, mechanical vibrations, direct sunlight, or heavy dust. Using your device in extreme environments for long periods of time can result in product deterioration and a shortened product life.
- Do not place heavy objects on top of the notebook as this may damage the display.
- Do not operate in an environment with metallic dust.
- Store and use your notebook on a flat and steady surface. Do not stand the notebook on its side or store it in an upside-down position. The impact from dropping or an object hitting the device may cause damage.

- Do not cover or block any ventilation openings on the notebook. For example, do not place the notebook on a bed, sofa, rug, or other similar surface. Overheating may occur, which could result in damage to your notebook.
- Keep your notebook away from objects that are vulnerable to heat damage, as the device can become very hot during operation.
- Keep your notebook at least 13 cm (5 inches) away from electrical appliances that can generate a strong magnetic field such as a TV, refrigerator, motor, or a large audio speaker.
- Avoid moving your notebook abruptly from a cold to a warm place. A temperature difference of more than 10°C (18°F) may cause condensation inside the unit, which may damage storage media.

Display and Touchscreen Guidelines

- Use your finger or the included stylus on the touchscreen surface. Using a sharp or metallic object, such as a pen or pencil, may scratch and damage the display, thereby causing errors.
- Use a soft cloth to remove dirt on the display. The touchscreen surface has a special protective coating that prevents dirt from sticking to it. Not using a soft cloth may cause damage to the special protective coating on the touchscreen surface.
- Turn off the notebook power when cleaning the display. Cleaning the display with the power on may cause improper operation.
- Do not use excessive force on the display. Avoid placing objects on top of the display as this may cause the glass to break, thereby damaging the device.
- Expect a slower response time when using the touchscreen at lower temperatures (less than 5°C or 41°F). A normal response time may be restored upon returning to room temperature.
- Refer to Windows online support for instructions on recalibrating the touchscreen display when there is a noticeable problem with the touchscreen function (e.g., improper display resolution or unresponsive touchscreen).
- LCD image sticking occurs when a fixed pattern is displayed on the screen for a prolonged period of time. You can avoid the problem by limiting the amount of static content on the display. It is recommended that you either use a screen saver or turn off the display when it is not in use.
- To maximize the life of the backlight display, allow the backlight to automatically turn off as a result of power management.

Battery Pack Guidelines

- Do not expose the battery to temperatures below 0°C (32°F) or above 46°C (115°F). This may adversely affect the battery pack.
- While the battery may not provide 100% capacity at temperature extremes, its capacity is restored when the battery temperature return to a normal range, around 20°C (68°F).
- Your battery will last longer during the day if it is used, charged and stored between 50°F and 86°F (10°C and 30°C).
- Charge the battery nightly where the temperature will remain around 68°F (20°C). Your battery may not last as long through the day if you charge it at higher or lower temperatures.
- Allow unrestricted airflow while the device is connected to external power. Make sure that the fan inlet and outlet are unobstructed.
- Avoid exposure to extreme temperatures for long periods as this can shorten battery charge life or damage the battery.
- If your battery is charged in a cold (less than 5°C/41°F) or very warm (greater than 45°C/113°F) environment, it is possible that the Battery LED will indicate that the charge has stopped; However, this does not necessarily mean that your battery is fully charged.
- Read and follow all battery precautions in the Safety section.
- Use only batteries of the same kind as replacements.
- Turn the power off before removing or replacing batteries.
- To avoid malfunction of the tablet PC and losing any unsaved data, do not install or remove the battery pack while the device is in sleep mode.
- Avoid touching the contacts of the battery while installing or removing the battery. Hold the battery by the sides instead to prevent the malfunction of the system.
- Do not tamper with the batteries.
- Keep batteries away from children.
- Before storing your battery, read and follow the recommendations in the Battery Tips section.
- Dispose of used batteries according to local regulations.
- Recycle if at all possible.

Battery Charging Recommendations

The battery is a consumable item that will eventually wear out and need replacement.



NOTE

- If the battery pack has deteriorated, ensure it is replaced with a new one.

The lifespan of the battery depends upon its usage. To prolong battery life, follow the recommendations below:

- Keep the number of charges and discharges to a minimum. It is best to charge the device no more than once a day and only when the charge drops to 10% or lower.
- Monitor the temperature inside the battery to prevent it from becoming too high. Charge your device indoors in an open area where the temperature is between 50°F and 86°F (10°C and 30°C).
To further enhance battery charging and prolong battery life, we advise charging the battery nightly, where the temperature will remain around 68°F (20°C).
- Charging the battery while the system is fully running will take longer. We recommend charging the battery when the system is in hibernation or sleep mode to increase the charging speed.

Cleaning Your Notebook

Cleaning the Outside Case

- Disconnect external power and turn off the device.
- Remove the battery.
- Add a small amount of water to a soft cloth and clean the device case. Do not use paper products because they can scratch the surface.
- Wipe off any excess liquid with a soft cloth.
- Reinstall the battery.

CAUTION!

Aerosols, solvents, or strong detergents are not recommended cleaning solutions and may void your warranty. For system decontamination recommendations please contact your support representative.

Cleaning the Display

Use a soft, dry cloth. In some cases, you can use a small amount of water to remove streaks or smears. For difficult display cleaning tasks, use a 50/50 mixture of isopropyl alcohol and water. Do not use paper products because they can scratch the screen.

Cleaning the External Power Connector

The external power connector may sometimes be exposed to moisture and/or contamination causing an unreliable connection to the external power source. Clean the connector with a cotton swab dipped in electronics grade isopropyl alcohol.

Cleaning the RJ-45 / USB Connectors

If the connector pins get dirty, clean the connector with a cotton swab dipped in electronics grade isopropyl alcohol.

Traveling With Your Notebook

Before traveling with your notebook, make sure you prepare and follow the precautions described below:

- Back up the data on your hard drive to a flash drive or other storage device. As an added precaution, bring an extra copy of your important data.
- Make sure that the battery pack is fully charged.
- Ensure that your notebook is turned off.
- Confirm that all the connector covers are closed completely to ensure the device's waterproof integrity.
- Disconnect the AC adapter from your notebook and take it with you. Use the AC adapter to power the device and charge the battery.
- Hand-carry your notebook onto an airplane, train, or bus. Do not check it in as luggage.
- If you need to leave your notebook in a car, store it in the trunk to avoid exposing it to excessive heat.
- When going through airport security, do not carry your notebook through the magnetic detector (the device you walk through) or expose it to a magnetic wand (the handheld device used by security personnel). It is recommended that you send the notebook and any flash drives through the X-ray machine (the device where you set your bags).
- If you plan to travel abroad with your notebook, consult your dealer for the appropriate AC power cord for use in your country of destination.

Troubleshooting

This chapter advises you on what actions to take when solving common computer problems that may be caused by issues with hardware or software.

Preliminary Checklist

Here are the initial steps you should follow before taking further action when encountering any problem:

1. Try to identify and isolate which part of the notebook is causing the problem.
2. Make sure that you turn on all peripheral devices before turning on the notebook.
3. If you are having trouble with an external device, make sure that the cable connections are correct and secure.
4. Make sure that the configuration information is properly set in the BIOS Setup program.
5. Ensure that all the device drivers are correctly installed.
6. Make note of your observations. Are there any messages on the screen? Do any indicators light up? Do you hear any beeps? Detailed descriptions are useful to the service personnel when you need to consult someone for assistance.
7. If any problem persists after you follow the instructions in this chapter, contact an authorized dealer for help.

Solving Common Problems

Battery Problems

The battery does not charge

- To prevent possible damage to the battery, the device does not allow the battery to charge if the internal temperature of the battery gets too low ($< 5^{\circ}\text{C}$ or $< 41^{\circ}\text{F}$) or too high ($> 50^{\circ}\text{C}$ or $> 122^{\circ}\text{F}$). If possible, charge the battery in a location with a moderate temperature of around 20°C (68°F).
- If possible, turn off the device while the battery is charging.
- If the battery is new or has been stored for a week or more, follow this procedure:
 1. Make sure the device is turned off.
 2. Remove the battery.
 3. Connect the AC adapter to the device and an AC wall outlet, and then turn on the device by pressing the  button.
 4. Let the device complete the boot process. Then reinstall the battery.

Troubleshooting

- Allow the system to remain idle for one hour with the AC adapter connected to the device.
- The Battery Power LED lights up when the battery starts charging.
- If the battery still fails to start charging after an hour, remove the battery, wait several seconds, and then install it again.
- If the battery does not begin charging within several minutes, return the unit for service.

The battery takes longer than seven hours to charge.

- Under moderate temperatures, about 20°C (68°F), the device's battery takes approximately 4 to 5 hours to completely charge.
- As the battery temperature approaches the end of its temperature range (5°C/41°F to 50°C/122°F), it may take longer to charge the battery.

The battery doesn't hold charge for very long.

- Calibrate the battery. If your battery is new or has not been used for several weeks, calibrating the battery accurately sets the gas gauge.
- As your battery ages, its maximum capacity naturally decreases and even the best maintained batteries eventually need to be retired. Consider replacing the battery if you are not getting the usage you need from it.
- To meet ENERGY STAR® requirements, Wake on LAN is enabled by default. If running on battery power, this may decrease battery run-time. To change Wake on LAN settings, open the Device Manager, Network Adapters and select the LAN device. Open the device Properties and select Power Management. Disable the Wake on LAN setting by unchecking. Allow this device to wake the computer.

The gas gauge isn't full after charging the battery.

- This may indicate that the charging process terminated prematurely.

The gas gauge reads "full," but the charging LED is still lit.

- If you charge your battery daily, rely on the gas gauge reading to determine battery capacity. The charging process may continue even if the gas gauge reads full. External power can be removed because the battery is virtually full.

My battery seems to have less and less capacity.

- If your battery is new, or if you are using it for the first time, you will need to calibrate it (see to Battery Calibration) prior to using it.
- As your battery ages, the maximum capacity that it can hold naturally decreases and even the best maintained batteries eventually need to be retired. Consider replacing the battery if you are not getting the usage you need from it.

Bluetooth Wireless Transmission Problems

I cannot connect to another device with Bluetooth wireless technology.

- Ensure that you have activated the Bluetooth feature on both devices.
- Make sure that the distance between the two devices is within the acceptable limit and that there are no walls or other obstructions between the devices.
- Confirm that the other device is not in a “Hidden” mode.
- Verify that both devices are compatible.

Display Problems

The display performance is slow.

- The temperature may be too cold. Move the device to a warmer operating environment.

The underlined, inverse, and hypertext characters are difficult to read on the screen.

- Select  > **Settings**  > **Personalization** > **Colors**. Then change the color and style of your Windows.

I changed my display resolution, but I see no difference on the screen.

- Select  >  > **Restart**.

Nothing happens when I try to use the stylus on my touch screen.

- If you cannot select objects accurately with the stylus, you may need to calibrate the touch screen.

The touch screen doesn't respond after a suspend.

- The touch screen needs a few seconds to work after a suspend. Wait a moment and try again.

Hard Disk Problems

The hard disk will not spin up, so the device can't boot up.


- This occurs if the unit is exposed to extremely low temperatures. This is not a hardware failure associated with the hard disk. The integrated hard disk drive heater will warm the drive to a safe operating temperature.

The device does not startup properly.


- Make sure you remove any USB drives from the unit before you start it.
- Connect the AC adapter to charge the battery if it is not charged.
- If the battery does not begin charging, perform the following:
 1. Remove the battery.
 2. Connect the AC adapter.
 3. Turn on the device by pressing the  button.
 4. Reinstall the battery. The battery LED is a steady orange while the battery is charging.

Storage recovery process in Windows 11


1. Select  > **Settings**  > **System** > **Recovery**.



2. Select any of the recovery methods that suits the best to solve the problem with your device.




- **Fix problems without resetting your PC:** Select this option to run a troubleshooter. Make sure your device is connected to the network.



- **Fix problems using Windows Update:** Select this option to reinstall your current version of Windows (your apps, files, and settings will be preserved). To reinstall your Windows, tap **Reinstall now**.

- **Reset this PC:** Select this option to reinstall the Windows 11 operating system. To reset your notebook, tap **Reset PC**. You are then prompted to keep or remove your personal files. Select either of the options and follow the on-screen instructions to complete the resetting procedure.



- **Advanced startup:** Select this option to restart your device with advanced startup features, including starting from a disc or USB drive. Follow the on-screen instructions to repair the system.

Other Problems

The device won't turn on.

- Make sure a fully charged battery is properly installed.
- Connect external power to charge the battery if it is not charged.
- If you are using the AC adapter, check the electrical outlet you are using to make sure it is working properly.
- If the device does not turn on, reset the device by holding down the  button for at least ten seconds, release it, and then press the  button again.

The device won't turn off.

- Select  >  > **Shut down**.
- If that does not work, press **Ctrl + Alt + Del** and then select **Task Manager**.
- If any programs are open, use your arrow keys to highlight each one and select End task. Repeat this until all programs are closed.
- If that still does not work, press and hold the  button for approximately ten seconds and then release it.

The device doesn't make any sounds, even during boot-up.

- You may have enabled Stealth Mode. Disable Stealth mode.

Appendix

Copyright

Copyright© 2025. All rights reserved.
No part of this user manual may be transmitted, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without the prior written permission of the manufacturer. Information is subject to change without prior notice.

Specifications

DURABILITY	– MIL-STD 810H certified (Drop, Shock, Vibration, Rain, Dust, Altitude, Freeze/Thaw, High/Low Temperature, Temperature Shock, Humidity) – 4' drop 26 faces – IP 53 certified – Aluminum-magnesium alloy chassis – Port covers – Removable quick-release batteries and storage drive – Optional sunlight readable display – Optional dual hot-swappable battery technology
OPERATING SYSTEM	Windows® 11 Pro 64-bit
PROCESSORS	– Intel® Core™ Ultra 5 125U (12MB Cache, up to 4.3 GHz, 12 cores, 14 threads with Intel® AI Boost NPU) – Intel® Core™ Ultra 5 135U (12MB Cache, up to 4.4 GHz, 12 cores, 14 threads with Intel® AI Boost NPU) – Intel® Core™ Ultra 7 155U (12MB Cache, up to 4.8 GHz, 12 cores, 14 threads with Intel® AI Boost NPU) – Intel® Core™ Ultra 7 165U (12MB Cache, up to 4.9 GHz, 12 cores, 14 threads with Intel® AI Boost NPU)
GRAPHICS	– Intel® Graphics – Optional NVIDIA® RTX A500¹
MEMORY	2 slots 16GB up to 64GB (5600MHz DDR5)

STORAGE	256GB NVME PCIE SSD – Optional 512GB/1TB/2TB PCIE SSD – Optional OPAL 2.0 SSD – Optional 2nd storage NVME PCIE SSD
DISPLAY	14.0" FHD (1920 x1080) – Optional 1200 nits DynaVue® sunlight readable display without touch screen – Optional 1200 nits DynaVue® sunlight readable display with capacitive multi-touch screen – User selectable touch mode for Finger/Water, Glove or Stylus programmable function
AUDIO	– Integrated microphone – Intel® High Definition Audio Compliant – Integrated speaker x 2 – Keyboard volume and mute controls
CAMERA	– Integrated 2.0 MP web-cam with shutter design – Optional 5.0 MP IR camera for Windows Hello¹
KEYBOARD & INPUT	– 2 user-definable keys (P1/P2) – Standard membrane keyboard with LED backlight
COMMUNICATIONS	– Integrated 10/100/1000 Ethernet – Intel® Wi-Fi 7 BE200 (802.11 be) – Bluetooth® V5.4 – Optional dedicated GPS module (UBLOX-NEO-M9N) – Optional 4G LTE multi-carrier mobile broadband – Optional 5G – Optional RF antenna pass-through for GPS, WWAN and WLAN

SECURITY	– Intel® vPro™ Technology – Secured-Core PC¹ – TPM 2.0 – NIST BIOS compliant – Easy removable SSD – Stealth mode – Kensington lock – Optional smart card reader³ – Optional Windows Hello¹ – Optional night vision mode² – Optional fingerprint scanner – Optional LF/HF-RFID (NFC) reader¹
I/O INTERFACES	– Thunderbolt 4 (type C) x 2 – USB 3.2 Gen 2 (type A) x 1 – USB 3.2 Gen 1 (type A) x 1 or 2³ – Audio in/out (combo jack) x 1 – microSD card (microSDXC) x 1 – 10/100/1000 Ethernet (RJ45) x 2 – HDMI 2.1 port (type A) x 1 – Serial port (RS232/RS422/RS485 : D-sub, 9-pin) x 1 or 2³ – Dual SIM (Nano SIM & eSIM) – DC-In jack x 1 – Optional smart card reader x 1³ – Optional ExpressCard 54 x 1³ – Optional docking connector (41-pin Pogo) x 1 – Optional RF antenna pass-through for GPS, WWAN, and WLAN
MEDIA BAY (One Option Only)	- Optional smart card reader - Optional ExpressCard 54 - Optional 2nd serial port (RS232) & USB 3.2 Gen 1 (type A)
EXPANSION BOX	- Optional discrete VGA¹

POWER	AC adapter: 100-240V, 50Hz-60Hz, 90W – Optional AC adapter (100-240V, 50Hz-60Hz, 120W), with NVIDIA® VGA Main battery Li-Ion, 10.8V, 6900mAh, 12 hours ⁴ – Optional 2nd battery Li-Ion 10.8V, 6900mAh, 12 hours ⁴ with dual hot-swappable battery technology
ENVIRONMENT	Temperature – Operating: -29°C ~ 63°C / -20°F ~ 145°F – Storage: -51°C ~ 71°C / -60°F ~ 160°F Humidity: 5% ~ 95%
DIMENSION & WEIGHT	– 350 mm (L) x 282 mm (W) x 38 mm (H) ⁵ – 2.37 kg ⁵
WARRANTY	3-year limited warranty standard

**NOTE**

¹ Contact your sales representative for feature availability.

² Night vision mode is available only for sunlight readable display.

³ Smart card reader, ExpressCard 54 and 2nd serial port (RS232) + 2nd USB 3.2 Gen 1 are mutually exclusive options.

⁴ Tested using the MobileMark 2014 battery life benchmark. Results may vary under different situations including hardware configuration, software, operating conditions, power management settings and other factors.

⁵ Weight varies with options. The dimension with optional discrete VGA is 61mm (H).

Regulatory Statement

Federal Communications Commission Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC Regulations

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Declaration of Conformity

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions:

- This device may not cause harmful interference
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC RF Radiation Exposure Statement

- This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
- Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems.

EU RoHS

This product complies with the EU RoHS Directive 2011/65/EU as amended by (EU) 2015/863.

The above criteria do not apply to the RoHS exemptions. Exemption item: 7a, 7(c)-1 and 6c.

REACH - Substances of Very High Concern (SVHC)

According to article 33 in EU REACH, article manufacturer has the obligation to disclose information of substances included in candidate list of SVHC contained in products. If used in product and encourage suppliers to reduce and phase out such substance in product if commercially available.

SVHC list is based on the publication by European Chemicals Agency (ECHA).

<http://echa.europa.eu/candidate-list-table/>

Cybersecurity Information

1. Security Update Period

The notebook has a software and hardware support period of 5 years. Detailed information can be obtained from

<https://www.durabook.com/en/support/security-advisory/>

2. Report on Security Issue

To report any vulnerability found with the notebook, user can submit the report through our vulnerability reporting page at

<https://www.durabook.com/en/support/security-advisory/>

Battery Statement



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- The compatible battery type CR2032.
- The nominal battery voltage DC 3V.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 60°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- This product contains a non-replaceable button cell or coin battery.
- Consult an authorized service center or authorized retailers for product service or assistance on proper disassembly or assembly of the product.

Battery Disposal

THIS PRODUCT CONTAINS A LITHIUM-ION OR NICKEL-METAL HYDRIDE BATTERY. IT MUST BE DISPOSED OF PROPERLY. CONTACT LOCAL ENVIRONMENTAL AGENCIES FOR INFORMATION ON RECYCLING AND DISPOSAL PLANS IN YOUR AREA.

CLASS 2 LASER PRODUCT

IEC 60825-1:2014

Caution: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Wavelength: 650nm

Beam divergence: horizontal: 41°, vertical: 26.5°

Pulse duration and repetition rate: 16.8mSec

Maximum power or energy output: 1mW

Attention: L'utilisation des commandes ou réglages ou l'exécution des procédures autres que celles spécifiées dans les présentes exigences peuvent être la cause d'une exposition à un rayonnement dangereux.

La longueur d'onde: 650nm

La divergence du faisceau: horizontal: 41°, vertical: 26.5°

La durée et fréquence de répétition des impulsions:
16.8mSec

L'émission maximale de puissance ou d'énergie: 1mW



Illustrate for Party site number 573139:

Party site number means that the Factory which manufactured this
Rugged Notebook PC model S14

Factory Information:

Factory Name: TWINHEAD INTERNATIONAL CORP.

Factory Address:

31 HUAXI RD
DALIAO DISTRICT
KAOHSIUNG 831 TW

CAUTION FOR ADAPTER

THE TABLET PC IS FOR USE WITH DEDICATED AC ADAPTER.

BATTERY SAFETY

DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED.
REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE
MANUFACTURER. DISPOSE OF USED BATTERIES ACCORDING TO THE
MANUFACTURER'S INSTRUCTIONS.

CAUTION FOR RJ-45 (Optional)

The RJ-45 jack is not used for telephone line connection.

Safety Instructions

Always observe these safety instructions to ensure safe operation when handling the device.

- Do not place this device on an unstable table or surface. The device may fall, causing serious damage to its housing and components.
- Do not cover the device or block its air ventilation holes with any other objects.
- Do not use any sharp objects to tap on the display screen.
- Do not expose the device to direct sunlight and dusty environments.
- Keep the device away from excessive heat and humidity.
- Keep liquids away from the device.
- Keep the device away from any magnetic emitting devices, as this may affect the quality of the wireless signal reception.
- When using an AC adapter:
 - ✓ Place this device in a location close enough to an electrical outlet to accommodate the length of the power cord.
 - ✓ Operate this device only with the type of power source indicated on the marking label.
 - ✓ Disconnect the AC adapter from the electrical outlet if the device is not being used for an extended period.
- When cleaning the device,
 - ✓ Be sure to turn off the device fully and unplug the AC adapter before cleaning.
 - ✓ Wipe the device with a clean, dry cloth.
 - ✓ Do not use abrasive cleaners to clean the device.
- Do not attempt to disassemble or repair this device. Doing so will void the warranty.
- For hotspots, users can easily avoid touching the device by changing the way the device is held.
- For battery pack:
 - ✓ Replacement of a battery with an incorrect type that can defeat a safeguard.
 - ✓ Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
 - ✓ Leaving a battery in an extremely high temperature surrounding

environment that can result in an explosion or the leakage of flammable liquid or gas.

- ✓ A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- The equipment power supply cord shall be connected to a socket-outlet with earthing connection.

ShopFloor Date Code Format Description

Format	Type	Year (unit digit)	Week	Origin	Year (tens digit)	Serial number
Example	SY	0	17	0	1	12345
Date Code	2	1	2	1	1	5
Total code numbers	12					

Definition of the Date Code

First Date Code: Type

SY ... System (complete machine)

Second Date Code: Year (unit digit)

Last digit of the calendar year. Example: 2010 “0”, 2015 “5”

Third Date Code: Week

Week of the calendar year. Example: January 1 “1”, January 8 “2”

Fourth Date Code: Origin

0 ... Main Factory (Twinhead International Corp.)

Fifth Date Code: Year (tens digit)

Tens digit of the calendar year. Example: 2010 “1”, 2023 “2”

Sixth Date Code: Serial number

Unique 5-character sequence number assigned to the batch.

